



1.	QUAD-LOCK REGULAR 2.25" PANEL
2.	VERTICAL REINFORCEMENT AS SPECIFIED
3.	BRACE TO OTHER SIDE OF WALL AS SHOWN AT 12" [30cm] O.C. MAX.
4.	REMOVE QUAD-LOCK FOAM FOR THE WHOLE LENGTH OF STEEL ANGLE
5.	STEEL ANGLE WITH NELSON STUDS - CAST IN PLACE; ENSURE THAT INSIDE OF ANGLE IS FLUSHED WITH QUAD-LOCK FOAM FOR SMOOTH WALL FINISH TRANSITION
6.	FASTEN PLYWOOD TO QUAD-LOCK TIE FLANGES WITH 2 SCREWS AT 12" O.C. MIN
7.	HORIZONTAL REINFORCEMENT AS SPECIFIED
8.	CONCRETE AS SPECIFIED
9.	QUAD-LOCK TIE (6" BLUE SHOWN)

QUAD-LOCK
Building Systems Ltd.

Quad-Lock Building Systems Ltd.
7398 - 132nd Street
Surrey, BC V3W 4M7
Canada

888.711.5625 - Toll Free
604.590.3111
604.590.8412 - fax
www.quadlock.com

IT IS THE RESPONSIBILITY OF THE USER TO COMPLY WITH ALL APPLICABLE REGULATIONS AND BUILDING CODE REQUIREMENTS CONCERNING THE USE OF THESE PRODUCTS.

IT IS FURTHER THE RESPONSIBILITY OF THE USER TO RESEARCH AND UNDERSTAND SAFE METHODS OF USE AND HANDLING OF THESE PRODUCTS.

STEEL LEDGE DETAIL

DATE:	2009-01-21	SCALE:	NOT TO SCALE
REVISION NO.:	R-02	PROJECT:	
REVISION DATE:	2009-07-10	CUSTOMER:	
DRAWN BY:	Z. PROSTRAN	APPROVED BY:	H.M.K. & D.J.B.
			DRAWING NO.:
			QL-715